


UltraMixer MIDI Map

For: Behringer BCD3000

The following midi map shows the Behringer BCD3000 midi controller. Each button and slider has a number which describes the corresponding function in UltraMixer (V. 2.1).



© Copyright 2007. BEHRINGER International GmbH

- [1] No MIDI function
- [2] No MIDI function
- [3] No MIDI function
- [4] Ext in A: Auto-DJ-Next, Ext in B: Talkover
- [5] Flanger (Player 1)
- [6] Cutoff (Player 1)
- [7] Flanger (Player 2)
- [8] Cutoff (Player 2)
- [9] Flanger on/off (Player 1)
- [10] Cutoff on/off (Player 1)

- [11] Flanger on/off (Player 2)
- [12] Cutoff on/off (Player 2)
- [13] Cue A: Monitor on/off (Player 1), Cue B: Monitor on/off (Player 2)
- [14] No MIDI function
- [15] No MIDI function
- [16] Monitor volume (Player 1/2)
- [17] Pitch mode (pitch/time) (Player 1/2)
- [18] No MIDI function
- [19] No MIDI function
- [20] Crossfader
- [21] Gain
- [22] Low (Hint: you can map the low knob to the UltraMixer high-knob in the MidiPreferences)
- [23] Switch between Mixer-Filearchive-Master
- [24] Loop in
- [25] Loop out / loop
- [26] SamplePlayer Slot 1
- [27] Mute
- [28] Volume
- [29] Play/Pause
- [30] Cue/Stop
- [31] Pitch bend (Hint: pitch bend buttons can be used as pitch value buttons to increase/decrease the pitch fader. =>MidiPreferences)
- [32] Pitch fader
- [33] Search
- [34] Pitch bend / framesearch